



Cable Tensioner Fitting Assembly Guide

<p>1</p>	<p>Slide the threaded ratchet stud onto the cable. Insert the cut end of the cable into the "smaller" diameter hole first and slide the stud down the cable leaving enough room for the jaw.</p>	<p>2</p>	<p>Slide the jaws onto the cut end of the cable with your fingers. The tapered end of the jaw should be pointing downwards. Leave approximately 1/8" of cable exposed above the jaw.</p>
<p>3</p>	<p>Pull the ratchet stud up into the jaw tightly with your fingers. You should hear a faint clicking sound as the grooves are snapping into place.</p>	<p>4</p>	<p>The assembled stud and jaw assembly should look like this.</p>
<p>5</p>	<p>Install the delrin washer onto the level fitting.</p>	<p>6</p>	<p>Insert the level fitting into the post and the jaw and stud into the level fitting turning the level fitting in a clockwise motion. Hold the cable steady so the cable does not spin with the level fitting. Stop when the stud is no longer visible.</p>

Please reference the Advantage horizontal cable railing installation guide located in the section box for complete post and cable railing installation.



JAM Systems

1750 15th Ave SE P.O Box 302 Dyersville, IA 52040 (563)875-2110 www.jamvinyl.com